



Keuze uit:

RKxx MO = RETRO KADER MODERN	
RKxx KL = RETRO KADER KLASSIEK	

Voor retro model RM1G, RM2G, RM13G, ...




RK1 KL	RK2 KL	RK3 KL	RK4 KL	RK5 KL	RK6 KL	RK7 KL	RK8 KL	RK9 KL	RK10 KL
RK1 MO	RK2 MO	RK3 MO	RK4 MO	RK5 MO	RK6 MO	RK7 MO	RK8 MO	RK9 MO	RK10 MO



RK11 KL	RK12 KL	RK13 KL	RK14 KL	RK15 KL	RK16 KL	RK17 KL	RK18 KL	RK19 KL	RK20 KL
RK11 MO	RK12 MO	RK13 MO	RK14 MO	RK15 MO	RK16 MO	RK17 MO	RK18 MO	RK19 MO	RK20 MO

Voor retro model RM17G, RM18G, RM23G, RM24G, ...



RKK1 KL	RKK2 KL	RKK3 KL	RKK4 KL
RKK1 MO	RKK2 MO	RKK3 MO	RKK4 MO